

Trainings ▾

Maintenance Check

Check the shutterstats and the thermatic fan.

Note : Parallel control systems are required for automatic radiator shutters and thermatic fans. Shutters **must** open and fans turn on whenever the intake manifold air temperature, the engine coolant outlet temperature, or the freon compressor pressure rises above their sensor set points. Any one of the following conditions **must** activate the shutters and/or fan:

- High coolant temperature
- High intake manifold temperature
- High freon compressor pressure.

Shutterstat and thermatic fan controls **must** operate in the same temperature range as the thermostat with which they are used. Refer to the Thermal Control Settings Graph in this section.

