

Trainings ▾

Install

Install a new fibrous insulator.

Install a new metal gasket.

Note : The fibrous insulator will be against the injector.

Install the aftertreatment injector onto the adapter pipe.

Note : Make sure the aftertreatment injector harness is not touching the adapter pipe.

Note : The tall side of the injector and injector heat shield should be facing the turbocharger side.

Install new capscrews. Anti-seize compound will already be applied to the capscrews.

The use of the original capscrews will result in clamp load loss and gasket leakage.

Torque Value: 11.3 n•m [100 in-lb]

