

Trainings ▾

Install

Install the aftertreatment injector assembly onto the adapter pipe. Refer to Procedure 011-042 in Section 11.

(</qs3/pubsys2/xml/en/procedures/101/101-011-042-tr.html>)

Install new gaskets on each end of the adapter pipe.

Place the exhaust adapter pipe in position with the pin in the correct location in the turbocharger.

Tighten the V-band clamps on each end.

Torque Value: 11 n•m [97 in-lb]

