

Trainings ▾

Install

Install the front bracket and capscrews.

Torque Value: 47 n•m [35 ft-lb]

Install the rear bracket and capscrews.

Torque Value: 81 n•m [60 ft-lb]

