



Trainings ▾

Engine Dataplate

Marine and Industrial Applications

The engine dataplate shows important facts about your engine. The engine serial number and CPL provide data for ordering parts and service. The engine dataplate **must not** be changed unless approved by Cummins Inc.

The dataplate is located on the fuel pump side of the engine, on the rocker housing. Have the following engine data available when communicating with a Cummins Authorized Repair Location. The following information on the dataplate is **mandatory** when sourcing service parts:



1. Engine serial number
2. Model
3. Horsepower and rpm rating
4. CPL
5. Emission statement (if applicable).


ECM Dataplate

Marine and Industrial Applications

There are two dataplates on top of the ECM.

The dataplate on the left contains the part number (P/N), serial number (S/N), and date code (D/C) of the ECM.

The dataplate on the right contains the engine serial number (ESN), ECM code, and date.




Cummins® Engine Nomenclature

Marine Applications

The Cummins® engine nomenclature provides the data as illustrated in the graphic.

Note : The following letters designate some of the different market applications for a Cummins® engine.

- A = agriculture
- C = construction
- M = marine
- G = generator drive.



Fuel Injection Pump Dataplate

The fuel pump dataplate is located on top of the fuel pump. It provides the data needed to calibrate the fuel pump.

