

Trainings ▾

Remove

Rear Gear Train

Note : Check the gasket while it is installed in the rocker housing. Once the gasket is removed it must be replaced.

Note : Check for cracks in the rocker housing bridge area before removing the mounting capscrews.

Remove the rocker housing, capscrews, and gasket.

