

Trainings ▾


Remove

Front Gear Train

For front gear train engines, the closed crankcase ventilation valve is located between the tappet cover breather and intake manifold/cover of the engine.

The tappet cover closed crankcase ventilation valve is held in place by the molded closed crankcase ventilation hoses.

Removing the hoses will remove the valve.



Rear Gear Train

For rear gear train engines, the closed crankcase ventilation valve is connected between the flywheel housing and intake manifold/cover of the engine.

The tappet cover closed crankcase ventilation valve is held in place by the molded closed crankcase ventilation hoses.

Removing the hoses will remove the valve.

