

## Trainings ▾

### Install

Apply a thin film of oil to the drain line o-rings.

Push the drain line into the drain line boss. Be sure both o-rings are completely seated in the bore.

Install the drain line capscrews with a new gasket.

**Torque Value:** 24 n•m [ 18 ft-lb ]

