

Trainings ▾

Install

⚠ CAUTION ⚠

If rubber grommets are used on the coolant lines, be sure they are installed carefully to prevent cuts or tears to the grommets which will cause leaks.

Install the coolant lines.

Torque Value: 24 n•m [18 ft-lb]

