


Trainings ▾

Tool Number

3375066

Pipe Plug Sealant

Used when installing pipe plugs to reduce the possibility of leaks.



Tool Number

3375068

Cup Plug Sealant

Used when installing cup plugs to reduce the possibility of leaks.



3375068

Tool Number

3824510

QD Spray Cleaner

Used to clean cup plug opening.

©Cummins Inc



oi8isea


Tool Number

3164085

Cup Plug Driving Tools (universal handle)

Required use with driver heads to install new cup plugs to their proper depth, plus avoiding damage to the cup plug and the surrounding area.

©Gummine Inc



3376795


Tool Number

3376816

Cup Plug Driving Tools (driver head, 1-inch nominal)

Required to install new cup plugs to their proper depth, plus avoiding damage to the cup plug and the surrounding area.

©Cummins Inc



3376816


Tool Number

3376817

Cup Plug Driving Tools (driver head, 1-1/4-inch nominal)

Required to install new cup plugs to their proper depth, plus avoiding damage to the cup plug and the surrounding area.

©Cummins Inc



3376817


Tool Number

3823520

Cup Plug Driving Tools (driver head, 11/16-inch nominal)

Required to install new cup plugs to their proper depth, plus avoiding damage to the cup plug and the surrounding area.

©Gummine Inc



3376817


Tool Number

3823524

Cup Plug Driving Tools (driver head, 2-1/4-inch nominal)

Required to install new cup plugs to their proper depth, plus avoiding damage to the cup plug and the surrounding area.

©Gummine Inc



3376817


Tool Number

3822372

Cup Plug Driving Tools

Required to install new cup plugs to their proper depth, plus avoiding damage to the cup plug and the surrounding area.

©Gummins Inc



3822372