

Trainings ▾

General Information

Perform maintenance at whichever interval occurs first. At each scheduled maintenance interval, perform all previous maintenance checks that are due for scheduled maintenance.

Marine Applications

Maintenance Procedures at Daily Interval

- Coolant Level - Check
- Fuel Water Separator - Drain
- Lubricating Oil Level - Check
- Marine Gear - Check¹
- Sea Water Strainer - Clean

Maintenance Procedures at 75 Hours or 3 Months

- Air Cleaner Restriction - Check
- Battery - Check
- Drive Belts - Check
- Electrical Connections - Check
- Engine Hoses - Check
- Sea Water Hoses - Check
- Zinc Anode - Inspect³

Maintenance Procedures at 300 Hours or 1 Year

- Aftercooler - Flush
- Air Cleaner Element - Clean
- Air Intake Piping - Inspect
- Engine Coolant Heater - Check
- Coolant Antifreeze - Check
- Engine Harness - Check
- Fuel Filter (Spin-On Type) - Change
- Fuel Water Separator Element - Replace
- Lubricating Oil and Filters - Change²
- Marine Gear Oil - Change
- Marine Gear Oil Cooler - Flush¹
- Radiator Pressure Cap - Check
- Sea Water Heat Exchanger - Flush
- Sea Water Pump - Inspect

Maintenance Procedures at 600 Hours or 2 Years

- Cooling Fan Belt Tensioner - Check
 - Cooling System - Flush⁴
 - Overhead Set - Adjust
 - Vibration Damper, Rubber - Inspect
 - Vibration Damper, Viscous - Inspect
1. Consult the marine gear manufacturer operator's manual for specifications and recommendations.
 2. Consult Section V of this manual for filter specifications.
 3. Depending upon the quality of electrical bonding and water conditions, increased maintenance is sometimes necessary.
 4. The cooling system requirement to Flush at this scheduled maintenance includes: Drain, Flush. and Fill.