



Trainings ▾

Flow Diagram





1. Gerotor lubricating oil pump
2. Pressure regulating valve closed
3. Pressure regulating valve open
4. From lubricating oil pump
5. To lubricating oil cooler
6. To lubricating oil pan
7. Lubricating oil cooler
8. Filter bypass valve
9. Filter bypass valve closed
10. Filter bypass valve open
11. To lubricating oil filter
12. Full-flow lubricating oil filter
13. From lubricating oil filter
14. Main lubricating oil rifle.



Lubrication for the Power Components


1. To valve train
2. Main oil rifle
3. From oil cooler
4. Connecting rod journal
5. To connecting rod bearing
6. Crankshaft, main journal
7. From main oil rifle
8. To camshaft
9. To piston cooling nozzle.



Lubrication for the Overhead

1. Main lubricating oil rifle
2. Rocker lever support
3. Transfer slot
4. Rocker lever shaft
5. Rocker lever bore
6. Rocker lever.

©Cummins Inc



Lubrication for the Turbocharger

1. Lubricating oil supply from oil pan
2. Lubricating oil pump
3. Lubricating oil filter head
4. Lubricating oil supply to turbocharger
5. Lubricating oil drain from the turbocharger.