

Trainings ▾

Select Service Tools

Recommended Cummins® Service Tools

- No Cummins® service tools required.

Additional Service Items

- No additional service items required.

General Information

The Marine C Command Connect and Connect Premier Panel System requires the original equipment manufacturer (OEM) to use a Cummins designed customer interface box (CIB) and engine interface harness.

The remaining system components (displays, sensors, etc.) and wiring harnesses can be designed and procured by the OEM as long as the components meet the Cummins Application Engineering guidelines and pass the installation quality assessment.

See equipment manufacturer service information for information on operation, removal, and installation of the OEM supplied components.

Use the following procedure for information on sensor connection with the Marine C Command Connect and Connect Premier Panel System. Refer to Procedure 208-002 in Section E.
(/qs3/pubsys2/xml/en/procedures/513/513-208-002.html)

At initial production release, the Marine C Command Connect and Connect Premier Panel System has the following sensor calibration tables loaded in the vessel personality file:

Sensor	Type
Exhaust Temperature Sensor	Resistive
Exhaust Temperature Switch	Normally open that closes above a temperature threshold
Fuel Level	Resistive
Rudder Angle	Resistive
Transmission Gear Oil Pressure	Voltage

Sensor	Type
Transmission Gear Oil Temperature	Resistive Note: The CIB converts the signal to voltage for the ED-4 to monitor.
In order for the correct values to display on the ED-4 display, the proper vessel personality file must be loaded containing associated sensor calibration tables. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) Use the following procedure for using the ED-4 to troubleshoot sensor issues. Refer to Procedure 015-035 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-035.html) Note : Some applications may use the engine control module (ECM) to monitor these sensors. Refer to engine service manual for more information.	

Last Modified: 27-Sep-2019
