


Trainings ▾

Remove

⚠ WARNING ⚠

This component or assembly weighs greater than 23 kg [50 lb]. To prevent serious personal injury, be sure to have assistance or use appropriate lifting equipment to lift this component or assembly.



Remove the 19 front gear housing capscrews.

Remove the front gear housing and gasket.

Discard the gasket.

Note : The dowel pins do not need to be removed unless they are damaged.