

Trainings ▾

General Information

Note : Two different piston and liner combinations are available for this engine platform. The ferrous cast ductile (FCD) piston must be used in combination with a nitrided cylinder liner. The steel piston must be used in combination with a high boron liner. Each of these pistons has a corresponding piston ring set that must be used. The piston ring sets are not transferable between the different piston types.

Remove

Use piston ring expander, Part Number ST-1269, or equivalent, to remove the piston rings.

