


## Trainings ▾

### Flow Diagram

©Cummins Inc



08600182

Compressor Coolant, Lubricant and Airflow

1. Air intake
2. Air outlet
3. Lubricating oil drain to lubricating oil pan
4. Lubricating oil supply
5. Engine coolant inlet
6. Engine coolant outlet.