

Trainings ▾

Inspect for Reuse

Inspect the fan shroud for the correct fan clearance. Refer to the vehicle manufacturer's specifications and the appropriate Installation Recommendations Bulletin.

Inspect the shroud for cracks, air leaks or other damage. Replace the part, if damaged. Refer to the manufacturer's instructions.

