

Is the Accelerator Position Sensor (CELECT™ Type Accelerator Pedal) used?	Go to 98-fc131ctap (/qs3/pubsys2/xml/en/procedures/98/98-fc131ctap.html)
Is the Accelerator Position Sensor (Non-CELECT™ Accelerator Pedal) used?	Go to 98-fc131nctap (/qs3/pubsys2/xml/en/procedures/98/98-fc131nctap.html)
Is the Accelerator Position Sensor (Accelerator Switch) used?	Go to 98-fc131as (/qs3/pubsys2/xml/en/procedures/98/98-fc131as.html)
Is the Accelerator Position Sensor (Frequency Accelerator) used?	Go to 98-fc131fa (/qs3/pubsys2/xml/en/procedures/98/98-fc131fa.html)

Last Modified: 27-Oct-2003
