

|                                                                              |                                                                               |
|------------------------------------------------------------------------------|-------------------------------------------------------------------------------|
| Is the Accelerator Position Sensor (CELECT™ Type Accelerator Pedal) used?    | Go to 98-fc432ctap<br>(/qs3/pubsys2/xml/en/procedures/98/98-fc432ctap.html)   |
| Is the Accelerator Position Sensor (Non-CELECT Type Accelerator Pedal) used? | Go to 98-fc432nctap<br>(/qs3/pubsys2/xml/en/procedures/98/98-fc432nctap.html) |

---

**Last Modified: 27-Oct-2003**

---