



Service Tool Instruction

Service Tool Instruction
Number: 3377887

Revision Level:

Released Date: 23-apr-
2002


Description

Injector Seal Replacer Kit

Purpose

The injector seal replacer kit, Part Number 3164197 is used to replace the oil seal on the injector for Signature, ISX and QSX15 Engines.

©Cummins Inc




22c00181

Table 1, Injector Seal Replacer Kit, Part Number 3164197


Item Number	Part Number	Description	Quantity
1	3164198	Injector holding fixture	1
2	3164206	Bracket	1
3	3164821	Flat head socket cap screw-M6x1x12	2
4	3398495	3/32 pin punch	1
5	3164199	Seal installer	1

To replace the injector oil seal, refer to the Troubleshooting and Repair Manual, Signature, ISX and QSX15 Engines, Bulletin 3666239.

Injector holding fixture, Part Number 3164198, is used to hold the injector while replacing the seal.



Use a 3/32 inch pin punch, Part Number 3398495, to remove the oil seal.



Seal installer, Part Number 3164199, is used to install the new seal.

