



Service Tool Instruction

Service Tool Instruction
Number: 3377954

Revision Level:

Released Date: 08-sep-
2003


Description

Gauge Mounting Base

Purpose

This document provides information for using gauge mounting base, Part Number 3165168. The base is used with dial indicator gauge, Part Number 3375006, to verify the wastegate actuator travel on the Signature, ISX, and QSX15 engines.

©Cummins Inc



22c00246

Table 1, Gauge Mounting Base, Part Number 3165168

Item Number	Part Number	Description	Quantity
1	3165162	Gauge mounting base	1
2	3165167	Magnet	1

Table 2, Items Used with the Gauge Mounting Base, Purchased Separately

Item Number	Part Number	Description	Quantity
3	3375006	Dial indicator gauge	1

Install the gauge mounting base and dial indicator gauge assembly onto the wastegate cover with the dial indicator gauge tip resting on the end of the wastegate lever.

Refer to Procedure 010-050

(</qs3/pubsys2/xml/en/procedures/10/10-010-050.html>) in the Troubleshooting and Repair Manual Signature, ISX, and QSX15 Engines, Bulletin 3666239 to verify the required wastegate actuator travel.

