

Trainings ▾

General Information

Note : Shutters and fan clutch must be set to operate in the same temperature range as the thermostat with which they are used.

Check the shutters and the fan clutch every 1500 hours.

Every 192,000 km [120,000 mi], 3000 hours, or 2 years, whichever comes first, check the shutters and the fan clutch.

Check the shutters in the closed position to be sure they are completely closed.

Note : If the shutters are not closed, refer to the manufacturer's instructions.

Be sure the shutters open completely at the desired temperature setting.

Note : If the shutters are closed, refer to the manufacturer's instructions.

