

Trainings ▾

Maintenance Check

⚠ WARNING ⚠

Never touch the wiring connections when the keyswitch is turned on. Electrical shock can result.

Check all wire connections and the wiring harness for damage. Faulty wiring can cause improper engine operation and poor performance.

