

## Trainings ▾

### Maintenance Check

Inspect the fuel injection pump mounting nuts, including the tail support bracket, for loose or damaged hardware.

