

Fault Code: 1438


Failed to Crank

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 1438 PID(P): SPN: FMI: Lamp: Warning SRT:	Fail to crank.	No action is taken by the ECM, although the engine will not start.

©Cummins Inc



19802494

Circuit Description

Component Location

Refer to Troubleshooting Fault Code t05-1438 (/qs3/pubsys2/xml/en/procedures/01/01-t05-1438.html)

