


Fault Code: 1442

Unswitched Battery Supply Circuit - Battery is Weak

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 1442 PID(P): SPN: FMI: Lamp: Warning SRT:	Battery is weak.	No action is taken by the ECM.



Unswitched Battery Supply Circuit

Circuit Description

The engine control module (ECM) receives unswitched battery input through the engine harness. There is an in-line 20 amp fuse in the unswitched positive (+) battery wire of the engine harness to protect the engine harness from overheating. The battery return wires are connected directly to the negative (-) battery post.

Component Location

The ECM is connected to the battery by the OEM harness. This direct link provides a constant power supply for the ECM. Refer to the OEM manual for the battery location.

Shoptalk

This fault is usually caused by loose or corroded battery connections.

Refer to Troubleshooting Fault Code t05-1442. (</qs3/pubsys2/xml/en/procedures/01/01-t05-1442.html>)

Last Modified: 08-May-2012
