


Fault Code: 1443

Unswitched Battery Supply Circuit - Battery is Dead

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 1443 PID(P): SPN: FMI: Lamp: Shutdown SRT:	Battery is dead.	Engine will not start.



Unswitched Battery Supply Circuit

Circuit Description

The engine control module (ECM) receives unswitched battery input through the engine harness. There is an inline 20-amp fuse in the unswitched positive (+) battery wire of the engine harness to protect the engine harness from overheating. The battery return wires are connected directly to the negative (-) battery post.

Component Location

The ECM is connected to the battery by the OEM harness. This direct link provides a constant power supply for the ECM. Refer to the OEM service manual for the battery location.

Shoptalk

This fault is usually caused by loose or corroded battery connections.

Refer to Troubleshooting Fault Code t05-1443. (</qs3/pubsys2/xml/en/procedures/01/01-t05-1443.html>)

Last Modified: 08-May-2012
