


Fault Code: 146

Engine Coolant Temperature High - Warning

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 146 PID(P): SPN: FMI: Lamp: Warning SRT:	Engine coolant temperature has exceeded the warning threshold for high coolant temperature.	Calibration dependent no action is taken by the ECM or engine shutdown as temperature increases over thresholds. Pre-High Engine Temperature relay driver is energized.



Coolant Temperature Sensor Circuit

Circuit Description

The coolant temperature sensor is used by the electronic control module (ECM) to monitor the temperature of the engine coolant. The coolant temperature is used by the ECM for the engine protection system, timing, and fueling control. If the voltage is low for more than 2 seconds, the ECM will log Fault Code 146.

Component Location

Refer to the Engine Diagrams. 100-002 (/qs3/pubsys2/xml/en/procedures/01/01-100-002.html) for the component location.

Shoptalk

Make sure the airflow through the radiator is **not** obstructed. The resistance of all the temperature sensors varies with the temperature.

Refer to Troubleshooting Fault Code t05-146 (/qs3/pubsys2/xml/en/procedures/01/01-t05-146.html)

Last Modified: 29-Jul-2010
