


Fault Code: 1491

Ready to Load Output Relay Driver Diagnostic

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 1491 PID(P): SPN: FMI: Lamp: Warning SRT:	The Ready to Load output relay driver diagnostic has detected an error.	Any customer systems/features dependent on the Ready to Load output will not function correctly. No action is taken by the ECM. No loss of performance.



The Ready to Load Output Relay Driver Circuit

Circuit Description

The ECM checks the Ready to Load output relay driver to ensure correct operation. The ECM uses the Ready to Load output to inform any customer systems/features dependent on the ECM for knowledge of when the generator set is ready to pick up load.

Component Location

Refer to section E for location of the output for the Ready to Load.

Shoptalk

The possible failure modes are open circuit, short circuit, short to ground, and loss of supply voltage inside the ECM.

Refer to Troubleshooting Fault Code t05-1491 (</qs3/pubsys2/xml/en/procedures/01/01-t05-1491.html>)

Last Modified: 29-Jul-2010
