


Fault Code: 236

Engine Speed/Position Sensor Circuit - Loss of Signal

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 236 PID(P): SPN: FMI: Lamp: Shutdown SRT:	Engine speed/position sensors signal is not detected.	Engine will shut down.



Engine Speed/Position Sensor Circuits

Circuit Description

The crankshaft and camshaft engine position sensor provides engine speed and position information to the electronic control module (ECM) through the engine harness.

Component Location

Refer to the Engine Diagrams. 100-002 (</qs3/pubsys2/xml/en/procedures/01/01-100-002.html>) for the component location.

Shoptalk

Possible causes of this fault code include damaged camshaft engine position sensor, open or shorted circuit, and power supply voltage failure.

Refer to Troubleshooting Fault Code t05-236 (</qs3/pubsys2/xml/en/procedures/01/01-t05-236.html>)

Last Modified: 29-Jul-2010
