


Fault Code: 421

Engine Oil Temperature High - Warning

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 421 PID(P): SPN: FMI: Lamp: Warning SRT:	Engine oil temperature has exceeded the warning threshold for high oil temperature.	No action is taken by the ECM. Possible loss of performance.



Oil Temperature Sensor Circuit

Circuit Description

The oil temperature sensor is used by the electronic control module (ECM) to monitor the temperature of the engine oil. The oil temperature becomes too high and engine protection is enabled, a derate condition could be incurred, possibly leading to shutdown.

Component Location

Refer to the Engine Diagrams. 100-002 (/qs3/pubsys2/xml/en/procedures/01/01-100-002.html) for the component location.

Shoptalk

The resistance of all the temperature sensors varies with the temperature.

Refer to Troubleshooting Fault Code t05-421 (/qs3/pubsys2/xml/en/procedures/01/01-t05-421.html)

Last Modified: 29-Jul-2010
