


Fault Code: 441

Battery 1 Voltage Low - Warning

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 441 PID(P): SPN: FMI: Lamp: Warning SRT:	Battery 1 voltage low - warning.	ECM voltage supply approaching level at which unpredictable operation will occur.



Unswitched Battery Supply Circuit

Circuit Description

The electronic control module (ECM) receives unswitched battery input through the engine harness. There is an in-line 20-amp fuse in the unswitched positive (+) battery wire of the engine harness to protect the engine harness from overheating. The battery wires are connected to the starters. The customer connects the batteries to the starters.

Component Location

The ECM is connected to the battery by the OEM harness. This direct link provides a constant power supply for the ECM. Refer to the OEM manual for the battery location.

Shoptalk

This fault is usually caused by loose or corroded battery connections.

Refer to Troubleshooting Fault Code t05-441 (</qs3/pubsys2/xml/en/procedures/01/01-t05-441.html>)

Last Modified: 29-Jul-2010
