


Fault Code: 556

Blowby Pressure - Critical Level

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 556 PID(P): SPN: FMI: Lamp: Shutdown SRT:	Engine blowby - critical level. Voltage signal indicates blowby pressure has exceeded the shutdown threshold for high blowby.	Engine will shut down.



Blowby Pressure Sensor Circuit

Circuit Description

The blowby pressure sensor is used by the electronic control module (ECM) to monitor the engine crankcase pressure. The ECM monitors the voltage on the signal pin and converts this to a pressure value. The blowby pressure value is used by the ECM for the engine protection system.

Component Location

Refer to the Engine Diagrams. 100-002 (/qs3/pubsys2/xml/en/procedures/01/01-100-002.html) for the component location.

Shoptalk

Confirm that the crankcase breathers and breather tubes are **not** obstructed.

Refer to Troubleshooting Fault Code t05-556 (/qs3/pubsys2/xml/en/procedures/01/01-t05-556.html)

Last Modified: 29-Jul-2010
