


Fault Code: 688

Engine Oil Level Number 1 High - Warning

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 688 PID(P): SPN: FMI: Lamp: Shutdown SRT:	Engine oil level Number 1 high - critical. Voltage signal indicates very high lubricating oil level in the engine.	Engine will shut down.



Oil Level Sensor Circuit

Circuit Description

The oil level sensor is used by the ECM to monitor the amount of oil in the engine. High oil level detected can cause the engine to shut down or **not** start.

Component Location

Refer to the Engine Diagrams. 100-002 (/qs3/pubsys2/xml/en/procedures/01/01-100-002.html) for the component location.

Shoptalk

A 4-pin oil level sensor will **not** trigger Fault Code 688.

Refer to Troubleshooting Fault Code t05-688 (/qs3/pubsys2/xml/en/procedures/01/01-t05-688.html)

Last Modified: 29-Jul-2010
