


Trainings ▾

General Information


ECM calibrations can be performed by the INSITE™ electronic service tool.



The ECM calibration process occurs with the keyswitch in the ON position.

Always follow the instructions on the service tool screens.

Note : If the tool will **not** communicate with the keyswitch in the ON position, cycle the keyswitch and try again.



Connect the electronic service tool to the service tool datalink, located on the diagnostic tool panel.

Refer to the help section with INSITE™ for detailed ECM calibration procedures.

