

Trainings ▾

General Information

- Engine Operation Report - Maintenance Check
- Lubricating Oil Level - Maintenance Check
- Coolant Level - Maintenance Check
- Unusual Engine Noises - Maintenance Check
- Fan, Cooling - Maintenance Check
- Fuel-Water Separator - Drain
- Air Cleaner Precleaner - Maintenance Check
- Air Cleaner Element - Maintenance Check
- Air Intake Piping - Maintenance Check
- Air Cleaner Restriction Indicator - Maintenance Check
- Air Cleaner Element - Clean
- Air Tanks and Reservoirs - Drain
- Water Inlet Screens (Marine Only) - Maintenance Check
- Lubricating Oil and Filters - Change ⁽¹⁾
- Coolant Filter - Change
- Fuel Filter - Change
- Supplemental Coolant Additive (SCA) - Maintenance Check
- Crankcase Breather- Clean
- Air Compressor Air Cleaner Element - Clean
- Overhead Set - Adjust
- Cooling System Hoses - Replace
- Cold Starting Aid - Maintenance Check
- Batteries - Maintenance Check
- Engine Mounting Bolts - Maintenance Check
- Crankshaft End Clearance - Maintenance Check
- Zinc Anode - Inspect
- Turbocharger Mounting Bolts - Maintenance Check
- Turbocharger - Inspect
- Vibration Damper - Inspect
- Air Compressor - Maintenance Check
- Fan Hub, Belt Driven - Maintenance Check
- Coolant System - Flush
- Water Idler Pulley Assembly - Maintenance Check
- Water Pump - Maintenance Check

- Alternator
 - Generator
 - Starter
 - Air Compressor (Non Cummins)
 - Electrical Connections
 - Batteries
 - Freon Compressor
 - Hydraulic Governor
1. Perform maintenance at whichever interval occurs first. At each scheduled maintenance interval, perform all previous maintenance checks which are due for scheduled maintenance
 2. For standby generator sets, perform maintenance at 250 hours or 1 year
 3. Test SCA concentration level every six months unless concentration is over three units; then check at every oil drain interval until concentration is below three units.
 4. Follow the manufacturer's recommended maintenance procedures for the starter, alternator, generator, batteries, electrical components, engine brake, exhaust brake, charge air cooler, air compressor, air conditioner compressor, and fan clutch. Refer to Procedure 203-001 (</qs3/pubsys2/xml/en/procedures/99/99-203-001.html>) for addresses and telephone numbers.