

Trainings ▾

General Information

Follow the Normal Starting Procedure in this section. In cold weather, the engine can run longer at idle but **only** until the minimum specified oil pressure is detected by the engine control module (ECM).

Using Starting Aids

Cold weather starting aids are available for the engine. Contact a Cummins® Authorized Repair Location for more information.

