

Trainings ▾

Preparatory Steps

This procedure describes the proper method for the short term storage (1 to 12 months) of an engine.

- Operate the engine until the coolant temperature is 70°C [160°F].
- Shut the engine down.
- Drain the oil pan sump and oil filters.
- Install the oil pan drain plugs. The oil pan can remain empty until the engine is ready to be put back into service.
- Close the manual fuel shutoff valve.

Note : It is **not** necessary to drain the coolant if it is a permanent type antifreeze with rust inhibitor.

- Drain the coolant.
- Put a warning tag on the engine controls. The tag **must** read "The engine does **NOT** contain oil. Do **NOT** operate the engine."
- Store the engine in an area that is dry and has a uniform temperature.
- Bar the crankshaft two or three revolutions every 2 to 4 weeks.

Remove

This procedure describes the method for the removal of an engine from short term storage (1 to 6 months).

- Prime the lubricating oil system.
- Fill the oil pan sump.
- Change the fuel filter.
- Fill the coolant system, if necessary.
- Check the power supplies and control system batteries.
- Operate the pre-lube pump.
- Operate the coolant heaters, if installed.
- Start the engine. Refer to Procedure 000-002 (</qs3/pubsys2/xml/en/procedures/28/28-000-002-tr.html>) in Section 0. Refer to Procedure 007-037 (</qs3/pubsys2/xml/en/procedures/28/28-007-037-tr.html>) in Section 7.

