

Fault Code: 2619

Auxiliary Equipment Sensor Input 1 Engine Protection Critical - Special Instructions

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 2619 PID(P): SPN: 701 FMI: 31 Lamp: Amber SRT:	Auxiliary Equipment Sensor Input 1 Engine Protection Critical - Special Instructions. The air shutoff is activated from engine overspeed or operator's E-stop.	Engine shuts down if engine protection shutdown feature is enabled.



Air Shutoff (OEM Switch/Dual Output) and E-stop Circuit

Circuit Description

The circuit uses the OEM E-stop signal or engine overspeed to activate the air shutoff.

Component Location

The E-Stop button is located on the door of the customer interface box (CIB) panel.

Shoptalk

This is for engines with one or more OEM supplied air shutoff valves.

The air shutoff uses the OEM switch input for the emergency air shutoff stop. A switch closure from either the operator's E-stop or engine overspeed will cause the air shutoff to activate. Causes of this fault code are:

- Operator pushes engine stop button.
- Overspeed shutdown event as commanded by the ECM.

Refer to Troubleshooting Fault Code t05-2619 (</qs3/pubsys2/xml/en/procedures/122/122-t05-2619.html>)

Last Modified: 21-Sep-2010
