


Fault Code: 2562

Transmission (or Gearbox) Oil Temperature - Data Valid But Above Normal Operating Range - Most Severe Level

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 2562 PCODE(P): SPN: 175 FMI: 0 Lamp: Red SRT:	Transmission (or Gearbox) Oil Temperature - Data Valid But Above Normal Operating Range - Most Severe Level. Transmission (or gearbox) oil temperature sensor indicates the transmission (or gearbox) oil temperature is above the protection limit.	No engine protection for transmission oil temperature.



Transmission (or Gearbox) Oil Temperature Sensor Circuit

Circuit Description

Transmission (or gearbox) oil temperature sensor is used by the engine control module (ECM) to monitor the transmission oil temperature. The ECM monitors the voltage on the SIGNAL pin and converts it to a temperature value.

Component Location

The transmission (or gearbox) oil temperature sensor is located in the transmission.

Shoptalk

There are multiple ECMs for the engine models included in this manual. Each ECM has an individual source address that displays when INSITE™ electronic service tool is connected. When troubleshooting a fault code, use the source address displayed in INSITE™ electronic service tool to determine which ECM and circuit is affected.

This fault code indicates that the transmission (or gearbox) temperature has exceeded the protection limits for high transmission (or gearbox) temperature.

Refer to Troubleshooting Fault Code 2562. (</qs3/pubsys2/xml/en/procedures/00/00-t05-2562.html>)