

Fault Code: 4689

Water in Fuel Indicator Sensor Circuit - Voltage Below Normal or Shorted to Low Source

 Printable Version

Overview

Codes	Reason	Effect
Fault Code: 4689 PID(P): SPN: 97 FMI: 4 Lamp: Maintenance SRT:	Water in Fuel Indicator Sensor Circuit - Voltage Below Normal or Shorted to Low Source. Low voltage detected at the water in fuel indicator sensor circuit.	None on performance. No water in fuel warning available.



Water in Fuel Indicator Sensor Circuit

Circuit Description

The water in fuel indicator sensor is installed by the original equipment manufacturer (OEM). The water in fuel indicator sensor sends a signal to the engine control module (ECM) when a set volume of water has accumulated in the fuel filter. The water in fuel indicator sensor circuit contains two wires: a water in fuel indicator RETURN (sensor return 1) ground wire and a water in fuel indicator SIGNAL wire.

Component Location

The water in fuel indicator sensor is mounted by the OEM. See equipment manufacturer service information.

Shoptalk

There are multiple ECMs for the engine models included in this manual. Each ECM has an individual source address that displays when INSITE™ electronic service tool is connected. When troubleshooting a fault code, use the source address displayed in INSITE™ electronic service tool to determine which ECM or circuit is affected.

Possible causes for this fault code include:

- Signal circuit shorted to ground in the harness, sensor, or connector.

Refer to Troubleshooting Fault Code t05-4689. (</qs3/pubsys2/xml/en/procedures/123/123-t05-4689.html>)