


Trainings ▾

Cummins Engine Nomenclature

The model name provides identification data for the engine. Refer to the illustration for the model name identification.

The applications codes are:


- A = Agricultural
- C = Construction
- D = Generator drive
- F = Fire pump
- G = Generator set
- L = Locomotive
- M = Marine
- P = Power unit
- R = Railcar
- T = Tactical military.



Engine Dataplate

The engine dataplate shows specific information about the engine. The engine serial number (ESN), Control Parts List (CPL), model, horsepower and rpm ratings, and Environmental Protection Agency (EPA) information provide information for ordering parts and service needs.

The engine dataplate **must not** be changed unless approved by Cummins Inc.



Fuel Pump Dataplate

The fuel pump dataplate is located on the top of the fuel pump. It provides information for fuel pump calibration.

FUEL PUMP DATAPLATE

CPL	Fuel Code	Revision	Serial No.
0749	4219-A	840508	
3043327		3052282	
Service Part No.	Pump Production Part No.		

fp8plga

ECM Dataplate


The external ECM dataplate is located on top of the ECM.

The dataplate contains the following:

- ECM part number (P/N)
- ECM serial number (S/N)
- Manufacturer date code (D/C)
- Supplier identifier (S/I)
- Input voltage rating of the ECM (V/R).

The dataplate on the right contains engine and calibration information. This includes the engine serial number (ESN), ECM calibration date (Date), and ECM calibration code.

©Cummins Inc.



19400316