

ED-4 Source Address Conflict on Network

Symptoms

- Alarm Code 7414 is displayed.

How To Use This Tree

This symptom tree can be used to troubleshoot controller area network (CAN) symptoms. Start by performing Step 1 troubleshooting. Step 2 will ask a series of questions and will provide a list of troubleshooting steps to perform, depending on the symptom.

Shoptalk

- Possible causes include:
- Original equipment manufacturer (OEM) device on network
 - ED-4 source address.

Troubleshooting Summary

STEPS		SPECIFICATIONS
STEP 1.	Check the ED-4 display	
	STEP 1A. Check ED-4 software.	Latest vessel personality file (VPF) and software installed?
	STEP 1B. Check configuration in ED-4 setup.	ED-4 displays setup correctly?
	STEP 1C. Check the OEM device.	Alarm Code 7414 active?

STEP 1. Check the ED-4 display.

STEP 1A. Check ED-4 software.

Conditions :		
Turn system enable switch ON.		
Action	Specification/Repair	Next Step

• Verify latest VPF is downloaded in the display. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) • Verify the latest display software is downloaded in the ED-4 display. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Latest VPF and software installed? YES	1B
	Latest VPF and software installed? NO Repair : Download correct vessel personality file to the display from Cummins QuickServe® Online. Refer to Procedure 015-044 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-044.html) Download latest version of the display software from Cummins QuickServe® Online. Refer to Procedure 015-107 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-107.html)	Repair complete.

STEP 1B. Check configuration in ED-4 setup.

Conditions :

- Turn system enable switch ON.

Action	Specification/Repair	Next Step
--------	----------------------	-----------

Verify the source address of all ED-4 displays on the network. Refer to Procedure 015-108 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-108.html)	ED-4 displays setup correctly? YES	1C
	ED-4 displays setup correctly? NO Repair : An incorrect setup has been detected in the ED-4 display. Select the source address. Refer to Procedure 015-108 in Section 15. (/qs3/pubsys2/xml/en/procedures/513/513-015-108.html)	Repair complete.

STEP 1C. Check the OEM device.		
Conditions : - Turn system enable switch OFF. - Remove the OEM device from the network. - Turn system enable switch ON.		
Action	Specification/Repair	Next Step

• Wait 30 seconds. • Read the ED-4 display.	Alarm code 7414 active? YES Repair : Request a Cummins® Marine Application Engineer on site.	Repair complete.
	Alarm code 7414 active? NO Repair : Verify the OEM device source address is setup incorrectly. See equipment manufacturer service information.	Repair complete.