


Trainings ▾

General Information

⚠ WARNING ⚠

Lifting the QSK45 or the QSK60 engine improperly can cause equipment damage, severe personnel injury, or death. Lifting must be completed by trained, experienced technicians in accordance with instructions in this manual.



The procedures required to replace an engine will vary with different engine models, the type of equipment, optional equipment, and the shop facilities. Use the following procedures as a guide.

Note : All removal and replacement steps do not apply to all types of equipment. Complete only the steps that apply to the equipment involved. Use the OEM's recommendations and precautions for the removal and installation of chassis components needed to gain access to the engine.