


Trainings ▾

Remove

⚠ WARNING ⚠

This component or assembly weighs greater than 23 kg [50 lb]. To prevent serious personal injury, be sure to have assistance or use appropriate lifting equipment to lift this component or assembly.



Remove the seven cylinder head mounting capscrews.

Remove the cylinder head.

Remove and discard the cylinder head gasket.