

Trainings ▾

Remove with Mechanically Actuated Injector

Remove the electronic control valve body assembly mounting capscrews, electronic control valve body assembly, and gasket.

The fuel control valve body assembly gasket is an edge-molded gasket. Inspect the gasket, if any damage is found it **must** be replaced.

