


Trainings ▾

Install

⚠ CAUTION ⚠

To reduce the possibility of capscrew failure, replace any 9.8 grade belt tensioner mounting capscrew with a 10.9 grade mounting capscrew.



Install the belt tensioner and capscrew.

Tighten the capscrew.

Torque Value: 65 n•m [48 ft-lb]

Install the drive belt.

