

Cylinder Head


Tool Number

3163328

Cylinder Head Capscrew Length Gauge

Used to check the length of the cylinder head capscrews.

©Cummins Inc




Tool Number

3163606

Valve Spring Compressor Kit

Used to compress the valve spring to allow the valve to be removed or installed. Use with valve spring compressor plate, Part Number 3163177.




Tool Number

3375960

Valve Spring Compressor

Used to compress the valve spring to allow the valve to be removed or installed. This tool is air-operated.

©Cummins Inc



22800430


Tool Number

3164438

Depth Gauge Assembly

Used to measure cylinder liner counterbore ledge angle and injector protrusion.

©Cummins Inc



22600381


Tool Number

ST-685

Valve Seat Grinding Machine

Used to grind the valve seats.

©Cummins Inc



kn8togi


Tool Number

3824277

Valve Vacuum Tester - 115 VAC, 50/60 Hz

This valve vacuum tester provides all the necessary vacuum cups and seals needed to determine if the valves are properly seated in the cylinder head, using vacuum to provide a positive test.

©Cummins Inc



kn8togr


Tool Number

3824278

Valve Vacuum Tester - 220 VAC, 50/60 Hz

This valve vacuum tester provides all the necessary vacuum cups and seals needed to determine if the valves are properly seated in the cylinder head, using vacuum to provide a positive test.

©Cummins Inc



kn8togr


Tool Number

4918189

Intake Valve Insert Remover

Used to remove the valve seats. Used with slide hammer/shaft assembly 3376617 (purchased separately).

©Cummins Inc



kn8togx


Tool Number

3376799

Exhaust Valve Seat Remover

Used to remove the valve seats. Used with slide hammer/shaft assembly 3376617 (purchased separately).

©Cummins Inc



kn8togx

Tool Number

3375182

Valve Spring Tester

Used to test the valve springs.

©Cummins Inc



kn8togs

Tool Number

3375805

Valve Lapping Compound

Used this abrasive compound to lap the valves.

©Cummins Inc



3377132


Tool Number

3164984

Valve Head Thickness Gauge

Used to check the intake and exhaust valve head thickness after reconditioning.

©Cummins Inc



02400079


Tool Number

ST-1319

Water Tube Driver

Used to push the tubes toward the front and rear of the engine and to push the tube until it clears the rocker lever housing.

©Cummins Inc



st-1319


Tool Number

3163399

Valve Guide/Seal Remove and Install Tool

Used to install valve stem seals over the valve guide without causing damage to the seal lip face of the valve guide. It can also be used to remove the valve guide from the cylinder head.

©Cummins Inc



22400196


Tool Number

ST-257

Valve Seat Insert Tool

Use this kit with appropriate cutters to counterbore cylinder heads for the installation of valve seat inserts. A valve stem guide arbor must also be used to align the cutter with the counter bore. This tool is designed to be driven with a 1/2-inch electric drill.

©Cummins Inc



kn8toge


Tool Number

3376405

Valve Seat Grooving Kit

This grooving tool contains a high speed motor and a special cutter to cut a groove in the valve seat inside diameter prior to removal. The groove is sometimes required to allow the valve seat extractors a suitable area to grip. This tool will extend the life of the valve seat extractor.

©Cummins Inc




Tool Number

3376795

Cup Plug Driver Handle

Used with the cup plug drivers to install cup plugs into the cylinder head.

©Cummins Inc



oi8togh

Tool Number

3376813

Cup Plug Driver

Cup plug drivers are required to install new cup plugs to their proper depth plus avoid damage to the cup plug and surrounding area. Used with cup driver handle, 7/8-inch nominal diameter.

©Cummins Inc



bp8toge

Tool Number

3376814

Cup Plug Driver

Cup plug drivers are required to install new cup plugs to their proper depth plus avoid damage to the cup plug and surrounding area. Used with cup driver handle, 1 5/8-inch nominal diameter.

©Gummins Inc




bp8toge

Tool Number

3164341

Cylinder Head Leak Test Kit

Used to check for coolant passage leaks on the cylinder heads.




22400165

Tool Number

3164021

Thread Salvage Kit

Used to salvage cylinder head capscrew threads in the engine block




02600059

Tool Number

4918779

Drop Gauge

Used to check the valve guide for proper inside diameter and straightness.




Tool Number

3163041

Valve Guide Installer

Used to install the valve guide into the cylinder head. It also controls the height from the cylinder head machined top deck.

©Cummins Inc



02400079