


Trainings ▾

Cooling System

Tool Number
ST-647
Gear Puller
Used to remove the water pump pulley and impeller.
©Cummins Inc ad8toga




Tool Number

3377260

Water Pump Seal Driver

Used to install the ceramic seal on the water pump driveshaft.

©Cummins Inc



3377260-h


Tool Number

3824836

Water Pump Seal Driver

Used to install the ceramic seal on the water pump driveshaft.

©Cummins Inc



22600220


Tool Number

3375318

Water Pump Bearing Mandrel

Used to press the bearing and shaft into the water pump body.

©Cummins Inc



3824117


Tool Number

3375326

Bearing Separator

Used to hold the bearing when removing it from the shaft.

©Cummins Inc



3375326


Tool Number

3375411

Thermostat Seal Driver

Used to install the thermostat seals.

©Cummins Inc



Tool Number

3377438

Fluorescent Tracer Dye

Used with black light, Part Number 3163337, to find coolant leaks.

©Cummins Inc



3376891


Tool Number

3163337

Black Light Lamp Kit

Used in conjunction with fluorescent tracer dye, Part Number 3376891, to check for oil or Part Number 3377438, to check for coolant leaks.

©Cummins Inc



3163337


Tool Number

3377462


Digital Optical Tachometer


Used to measure the rpm of the fan.

©Cummins Inc



3377462,

Tool Number	
3377464	
Reflective Tape	
Used with optical tachometer, Part Number 3377462, to measure the rpm of the fan.	
	
	3377464

Tool Number	
CC-2602	
Cooling System Test Kit - Fleetguard®	
Used to measure supplemental cooling additive (SCA) concentration.	
	
	08600205


Tool Number

1650

Snap-On Pry Bar

Used to remove the thermostat seals.

©Cummins Inc



22600221

Last Modified: 11-Jul-2007
