

Trainings ▾

General Information

The following publications can be purchased by contacting a Cummins Inc. Distributor:

Bulletin	Title of Publication
4021530	QSK45 and QSK60 Series Service Manual
3666393	QSX15/QSK45/60 Generator-Drive Control System, Troubleshooting and Repair
3666394	QSX15/QSK45/60 Generator Set Power Command Control Version 3200, Troubleshooting and Repair
4021533	QSK38, QSK50 and QSK60 (Modular Common Rail System) Troubleshooting and Repair
2883394	QSK60 CM2150 Modular Common Rail Systems Drill Rig with C Command Elite™, and C Command Elite Plus™ Panel System Wiring Diagram
3666347	QSK45/60 Generator-Drive Control System Wiring Diagram
3666351	QSK45/60 Wiring Diagram
3666357	QSK45/60 CENSE™ Phase 1.0 Wiring Diagram
3666465	QSK45/60 PowerCommand® Control Version 3200 with Control Housing 1 Wiring Diagram
4021349	QSK60 Wiring Diagram
4021380	QSK45, QSK60, and QSK78 Generator-Drive Control System Wiring Diagram
4021406	QSK45 and QSK60 PowerCommand® Control 3200 with Control Housing 1 and Centinel™ Wiring Diagram
4021407	QSK45 and QSK60 PowerCommand® Control 3200 with Control Housing 2 Wiring Diagram
4021408	QSK45 and QSK60 PowerCommand® Control 3200 with Control Housing 2 and Centinel™ Wiring Diagram

Bulletin	Title of Publication
4021410	QSK45 and QSK60 Phase 2.0 Industrial without CENSE™ Wiring Diagram
4021412	QSK60 Phase 2.0 Industrial with CENSE™ Wiring Diagram
4021413	QSK45 Phase 2.0 Industrial with CENSE™ Wiring Diagram
4021414	QSK60 CENSE™ Phase 1.5 Wiring Diagram
4021534	QSK60 Industrial CM850 Control Module Wiring Diagram
4021542	QSK60 Power Generation Modular Common Rail System Wiring Diagram
4021593	Marine Auxiliary C Command™ Panel System Wiring Diagram
4021594	Marine Propulsion C Command™ Panel System Wiring Diagram
4021621	Marine Propulsion C Command Elite Plus™ Panel System Wiring Diagram
4021622	Marine Auxiliary C Command Elite Plus™ Panel System Wiring Diagram
4021623	Marine Auxiliary C Command Elite™ Panel System Wiring Diagram
4021624	Marine Propulsion C Command Elite™ Panel System Wiring Diagram
4022083	QSM60 MCRS CM850 Marine Auxiliary with C Command™ Panel System Wiring Diagram
4022084	QSM60 MCRS CM850 Marine Auxiliary with C Command Elite™ and Elite Plus™ Panel System Wiring Diagram
4022085	QSM60 MCRS CM850 Marine Propulsion with C Command™ Panel System Wiring Diagram
4022086	QSM60 MCRS CM850 Marine Propulsion with C Command Elite™ and C Command Elite Plus™ Panel System Wiring Diagram
4022102	QSK38, QSK50, QSK60 CM2150 Electronic Control System Troubleshooting and Repair Manual
4022116	QSM60 CM2150 Modular Common Rail Systems Industrial Wiring Diagram

Bulletin	Title of Publication
4022118	QSK60 CM2150 Modular Common Rail Systems Marine Propulsion with C Command™ Panel System Wiring Diagram
4022119	QSK60 CM2150 Modular Common Rail Systems Marine Propulsion with C Command Elite™ and Elite Plus™ Panel System Wiring Diagram
4022120	QSK60 CM2150 Modular Common Rail Systems Marine Auxiliary with C Command™ Panel System Wiring Diagram
4022121	QSK60 CM2150 Modular Common Rail Systems Marine Auxiliary with C Command Elite™, and C Command Elite Plus™ Panel System Wiring Diagram
3666260	QSK45 and QSK60 Operation and Maintenance Manual
4915528	QSK45 and QSK60 Owners Manual
4021587	Master Repair Manual, Marine C Command™ Panel System
4021617	Master Repair Manual, Marine C Command Elite™ and C Command Elite Plus™ Panel System
3666121	Holset® Air Compressor Master Repair Manual
3666253	Eliminator™ Filter Introduction Service Bulletin
3379000	Air For Your Engine
3387622	Cold Weather Operation
3666132	Cummins® Coolant Requirements and Maintenance
3669001	Fuels for Cummins® Engines
3810340	Cummins® Engine Oil Recommendations